This Notebook computes and displays various processing algorithms on an image captured with a webcam. Processing is done mainly using OpenCV. The processing includes:

- 1. Capturing photo with webcam
- 2. Decomposing to R,G,B values
- 3. Converting to grayscale
- 4. Face and eye detection
- 5. Blurring
- 6. Sharpening
- 7. Denoising
- 8. Edge detection
- 9. Calculating the histogram

```
In [1]: import cv2
import numpy as np
from matplotlib import pyplot as plt
%matplotlib inline
import matplotlib.image as mpimg
```

```
In [4]: # Camera 0 is the integrated web cam on my netbook
        camera port = 0
        #Number of frames to throw away while the camera adjusts to light levels
        ramp frames = 30
        # Now we can initialize the camera capture object with the cv2. Video Capt
        ure class.
        # All it needs is the index to a camera port.
        camera = cv2.VideoCapture(camera port)
        # Captures a single image from the camera and returns it in PIL format
        def get image():
         # read is the easiest way to get a full image out of a VideoCapture obj
        ect.
         retval, im = camera.read()
         return im
        # Ramp the camera - these frames will be discarded and are only used to
         allow v412
        # to adjust light levels, if necessary
        for i in xrange(ramp_frames):
         temp = get image()
        print("Taking image...")
        # Take the actual image we want to keep
        camera_capture = get_image()
        file = "webcam imq.png"
        # A nice feature of the imwrite method is that it will automatically cho
        ose the
        # correct format based on the file extension you provide. Convenient!
        cv2.imwrite(file, camera capture)
        # You'll want to release the camera, otherwise you won't be able to crea
        te a new
        # capture object until your script exits
        del(camera)
```

Taking image...

In [5]: file = "webcam_img.png"
 from IPython.display import Image
 Image(filename=file)

Out[5]:



```
In [6]: file = "webcam_img.png"
    img = cv2.imread(file)
    b,g,r = cv2.split(img)

plt.imshow(r, cmap = 'gray', interpolation = 'bicubic')
    plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
    plt.title('r')
    plt.show()

plt.imshow(g, cmap = 'gray', interpolation = 'bicubic')
    plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
    plt.title('g')
    plt.show()

plt.imshow(b, cmap = 'gray', interpolation = 'bicubic')
    plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
    plt.title('b')
    plt.show()
```







```
In [7]: def rgb2gray(rgb):
    return np.dot(rgb[...,:3], [0.299, 0.587, 0.144])
    gray = rgb2gray(img)
    plt.imshow(gray, cmap = 'gray', interpolation = 'bicubic')
    plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
    plt.title('gray')
    plt.show()
```





```
In [8]: # img = cv2.imread(file)
        # img = cv2.imread("C:\Users\orly\Dropbox\Photos\Orly portraite\orly 5-2
        8-14.jpg")
        file = "webcam img.png"
        # print file
        img = cv2.imread(file,1)
        # print img
        plt.imshow(cv2.cvtColor(img, cv2.COLOR BGR2RGB))
        plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
        plt.title('Color image')
        plt.show()
        gray = cv2.cvtColor(img,cv2.COLOR BGR2GRAY)
        plt.imshow(gray,cmap = 'gray')
        plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
        plt.title('Gray image')
        plt.show()
        cascPath = 'haarcascade frontalface default.xml'
        faceCascade = cv2.CascadeClassifier(cascPath)
        faces = faceCascade.detectMultiScale(
            gray,
            scaleFactor=1.1,
            minNeighbors=5,
            minSize=(30, 30),
            flags = cv2.CASCADE_SCALE_IMAGE
        print faces
        cascPath = 'haarcascade eye.xml'
        eye cascade = cv2.CascadeClassifier(cascPath)
        for (x,y,w,h) in faces:
            img2 = cv2.rectangle(img,(x,y),(x+w,y+h),(0,0,0),2)
            roi_gray = gray[y:y+h, x:x+w]
            roi color = img[y:y+h, x:x+w]
            eyes = eye cascade.detectMultiScale(roi gray)
            for (ex,ey,ew,eh) in eyes:
                 img2 = cv2.rectangle(roi color,(ex,ey),(ex+ew,ey+eh),(0,255,0),
        2)
        plt.imshow(cv2.cvtColor(img, cv2.COLOR BGR2RGB))
        plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
        plt.title('face detection')
        plt.show()
```

Color image




Gray image



[[142 65 152 152] [162 258 112 112]]

face detection



Out[9]: True

```
In [10]: file = "webcam_img.png"
         img = cv2.imread(file)
         kernel = np.ones((5,5),np.float32)/25
         dst = cv2.filter2D(img,-1,kernel)
         unsharp = cv2.add(cv2.subtract(img,dst),img)
         plt.subplot(121),plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB)),plt.ti
         tle('Original')
         plt.xticks([]), plt.yticks([])
         plt.subplot(122),plt.imshow(cv2.cvtColor(dst, cv2.COLOR_BGR2RGB)),plt.ti
         tle('Averaging')
         plt.xticks([]), plt.yticks([])
         plt.show()
         plt.imshow(cv2.cvtColor(unsharp, cv2.COLOR_BGR2RGB))
         plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
         plt.title('unsharp mask')
         plt.show()
         cv2.imwrite("webcam_img_blurred.png", dst)
         cv2.imwrite("webcam_img_unsharp_mask.png", unsharp)
```

Original



Averaging



unsharp mask




Out[10]: True

```
In [11]: file = "webcam_img.png"
    img = cv2.imread(file)

    dst = cv2.fastNlMeansDenoisingColored(img,None,5,5,7,21)

plt.subplot(121),plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB)), plt.t
    itle('Original Image')
    plt.subplot(122),plt.imshow(cv2.cvtColor(dst, cv2.COLOR_BGR2RGB)), plt.t
    itle('Denoised Image')
    plt.show()
    cv2.imwrite("webcam_img_denoised.png", dst)
```



Out[11]: True

```
In [12]: file = "webcam_img.png"
    img = cv2.imread(file)
    edges = cv2.Canny(img,100,200)

plt.subplot(121),plt.imshow(cv2.cvtColor(img, cv2.COLOR_BGR2RGB),cmap =
    'gray')
plt.title('Original Image'), plt.xticks([]), plt.yticks([])
plt.subplot(122),plt.imshow(edges,cmap = 'gray')
plt.title('Edge Image'), plt.xticks([]), plt.yticks([])
plt.show()

plt.imshow(edges,cmap = 'gray')
plt.xticks([]), plt.yticks([]) # to hide tick values on X and Y axis
plt.title('Edges')
plt.show()
```

Original Image




Edge Image



Edges



```
In [13]: file = "webcam_img.png"
    img = cv2.imread(file)
    color = ('b','g','r')
    for i,col in enumerate(color):
        histr = cv2.calcHist([img],[i],None,[256],[0,256])
        plt.plot(histr,color = col)
        plt.xlim([0,256])
    plt.title('RGB Histogram')
    plt.show()
```



```
In [ ]:

In [ ]:
```